

The Wooden Suite Assembly Instructions

TRU View Slim



Included Parts

- 1) Top and bottom plates
- 2) Left and right side (U shaped pieces, front has screw holes)
- 3) Top Face (6" wide straight piece)
- 4) Bottom face (5" wide straight)
- 5) Screws

Tools Required for Assembly

Power Drill





ASSEMBLY INSTRUCTIONS

1) Lay top and bottom face panel flat with the screw holes facing away from each other.



2) Align left side with screw holes facing into grooves of the top and bottom panels.



3) Use screws provided to attach the left side to the top and bottom panels.



4) Repeat with the right side.



5) Place one of the panels with the slots up and align the face and sides onto the plate.

6) Use the provided screws in each screw hole to attach the panels.



7) Place the top panel with the slots facing down on top of the unit.

8) Use provided screws in each screw hole to attached the panels.

** Ensure to remove the TRU VIEW framing tabs before inserting the fireplace into the display.



