

Fireplace Reset Sequence

- 1) Turn the breaker off or unplug the unit. Similar to a cell phone , the unit sometimes needs a reboot
- 2) Switch the unit off at the unit, lift the glass off if required
- 3) Turn the on/off switch to OFF
- 4) Turn the breaker back on
- 5) Turn the on/off switch to ON
- 6) Using the remote only turn the display ON
- 7) Does it work?
- 8) Turn the heater on to the low setting
- 9) Does it work?
- 10) Turn the heater on to the high setting
- 11) Does it work?