

Change Moodlight



Advanced Series Models:

WM-BI-28-3421-BLKGLS, WM-BI-43-5123-BLKGLS, WM-BI-58-6421-BLKGLS
WM-BI-76-8221-BLKGLS, WM-BI-106-11524-BLKGLS

Amantii



Remove the front panel

1. Unplug the mood light wire connect.
2. Remove the mood light holder from 4 corners.
3. Change new mood light.
4. Fix the mood light stripe to the holders.



Mood light holder