

Models: ZECL-26-2923, ZECL-26-2923-FLUSHMT, ZECL-30-3226, ZECL-30-3226-FLUSHMT, ZECL-33-3624, ZECL-39-4134, ZECL-2939, INSERT-26-3825, INSERT-30-4026, INSERT-33-4230

1. Unscrew and remove the rear and the top panels from the unit.









- 2. Make note of the wire locations.
- Unplug the wires from the pcb board.
- Take off the pcb board.









3. Put a new PCB board back to the unit. Plug all the wires back.





Amantii

4. Reattach the rear and top panels. Carefully reattach the front glass surround







Amantii