

Change the flicker motor
Zero Clearance & Insert Series

Amantii



Models: ZECL-26-2923, ZECL-26-2923-FLUSHMT, ZECL-30-3226, ZECL-30-3226-FLUSHMT, ZECL-33-3624,
ZECL-39-4134, ZECL-2939, INSERT-26-3825, INSERT-30-4026, INSERT-33-4230

1. Unscrew and take off the rear panel from the unit.



Amantii

2. Unscrew the screw as shown in image 1

- pull the flicker assembly from the flicker motor end as shown in image 4

1.



4.




Amantii

3. Unscrew and remove the flicker motor and the bracket.




Amantii

4. Replace with a new motor.



Amantii

5. Screw back the flicker motor and plug in the wire.
- Put the flicker assembly back and screw in place.



Amantii

6. Reattach the top and back panels with screws.
Reattach the front glass surround.



Amantii