


40,50,60,72,88" Deep & Slim Models

# Replacing the Heater Panorama Series Models



Unscrew the glass bracket. Use bracket as shown to hook the glass gently pulling towards you. Remove glass and set in a safe place.









# Replacing the Heater Panorama Series Models



Unscrew four screws located on each side and remove the bracket.














Take out the media tray and mirror glass as shown.





Remove the media tray





NOTE: It is recommended to use two people to remove the glass. There are two holes at each side behind the mirror glass. You can put your finger in and take out the glass. You can use one hand to lit up the up panel let the glass easy to be taken out.

### Replacing the Heater Panorama Series Models



#### Unscrew the part from the top panel



You can see the top panel. The part show at the picture. Unscrew 10 screws. Using the handle, lift the panel away from the unit.



Please unplug the internal wire. It is better take a photo before you do it.

# Replacing the Heater Panorama Series Models





Unscrew 6 screws and take out the bad heater. Replace a new one. Plug the internal wire back and screw back all the part.